HYGIENE EQUIPMENT

COMPACT HYGIENE STATION WITH PASS-THROUGH (5 BRUSHES) BOOT CLEANING MACHINE 10.4021.00

The machine is designated for personal hygienic control when entering in and going out of working areas – cleaning of boots and disinfection of hands.

It consists of a hand disinfection unit with a turn style and pass-through boot cleaning machine.

The pass-through boot cleaning machine consists of five brushes with independent each, motor-gear injecting system cleaning agent, automatic injector dosing of cleaning concentrate. The photocell at the entrance switches on the brushes (cleaning time is adjustable). When going out of area, a second photocell working unlocks the turn-style of \(\frac{1}{3} \) turnover and switches on the brushes.

The station can be left or right execution.


The turn style rotation can be one-way.

A programmable controller SIEMENS, allowing settings of operating modes in a wide range, is used for station control.

The machine complies with the Council Directives No. 2006/42/EC and 2006/95/EC and USDA regulations.



HYGIENE EQUIPMENT



Technical data:

Power supply	V/Ph/Hz	400/3/50
Control voltage	V	24DC
Installed power	kW	~ 1.1
Water supply	bar	min 2
Water outlet	mm	Ø50
Weight	kg	~180
Passing time	sec	6-8

Dimensions:

Length of body (without steps)	mm	1150
Total length	mm	1810
Length of sole brushes	mm	300/Ø170
Height of boot brushes	mm	300/Ø280
Total width	mm	1170
Total height	mm	1640

HYGIENE EQUIPMENT





10.4031.00 - with boot cleaning

10.4221.55 - with disinfection bath

COMPACT HYGIENE STATION WITH PASS-THROUGH BOOT CLEANING MACHINE

Art. No	10.2021.00	20.2020.00	10.4021.00	10.4020.00	10.4031.00	10.4221.55
Dimensions (L,W,H mm)	1810/1170/1640		1810/1170/1640		2558/1350/1585	2610/1190/1630
Hand disinfection unit/sink	yes/no		yes/no		yes/no	yes/no
Turn style/gate	yes/no		yes/no		yes/no	yes/no
Disinfection bath/drip-off zone	no/no no/no		no	no/no	yes/yes	
Brushes - soles length /boots height (mm)	2x300/	/3x300	2x300/3x300		2x700/3x300	no/3x300
One-way/two-ways	one-	one-way two-ways		two-ways	one-way	
Execution left/right	right	left	right	left	right	right
Ground fixation/wall installation	yes/no		yes/no		yes/no	yes/no
Passing time (sec)	~ 8-10		~ 8-10		~ 12-14	~ 8-10
Instaled power (kW)	~1.1		~1.1		~1.2	~1
Power supply - electricity/water/steam/compresed air/drain	3x400 V / 5 bar water	0 Hz min. 2 drain DN50	3x400 V / 50 Hz min. 2 bar water drain DN50		3x400 V / 50 Hz min. 2 bar water drain DN50	3x400 V / 50 Hz min. 2 bar water drain DN50
Miscellaneous					with boot cleaning	with disinfection bath